

Material		Aluminum ASTM 6063 T5	DRAWING	钱稳	 Nanjing Meishuo Building Materials Co., Ltd Expansion Joint
Thickness		Clear Anodised	CHECKING	刘明辉	
Colour		Clear Anodised	APPROVING	刘云富	
Hardness		ASTM 6063 T5	Picture No.	8	

1. Clean the garbage and check whether the gap is equally wide and straight.
2. Make level
3. Make level with high strength of cement mortar. The width is more than 150mm.
4. Install the fire barrier. Then snap the ink line on the screed coat to confirm the sidelines of the aluminum base.
5. Install the water barrier. The side line of water barrier can't cover the ink line snapped. (Brush the special glue on the surface of the screed coat and the lower surface of the water barrier. After the glue is almost air drying, put water barrier on the screed coat.)

Material		Aluminum ASTM 6063 T5	DRAWING	钱稳	 Nanjing Meishuo Building Materials Co., Ltd Expansion Joint
Thickness		Clear Anodised	CHECKING	刘明辉	
Colour		Clear Anodised	APPROVING	刘云富	
Hardness		ASTM 6063 T5	Picture No.	8	

6. Install the aluminum base.
7. Nail the scree to make sure the base plate on a straight line. Or the aluminum plate can be mismatched when the centering bar bolt is screwed down,
8. Insert the rubber.